

Little Colorado[®] Inc.

Quality Wooden Children's Furniture and Accessories

Made in America • Established 1987

www.littlecolorado.com



WARNING: ADULT ASSEMBLY REQUIRED

WARNING: Assembly kit contains parts with sharp edges.

WARNING: Assembly kit contains parts with sharp points.

WARNING: Package contains plastic bags that present suffocation risks for children.

WARNING: Assembly kit contains small parts that present choking hazards for children.

Assembly Instructions For Child's Adirondack End Table Item #142

Contents: 1-Table top
4- Legs
12- 1 5/8" Wood Screws

1. Please inspect all parts for damage during shipping and for any missing items. If you suspect that there may be damage or a shortage, call us and we will send replacement parts if needed. At this time, visualize how the components fit together per the drawing and make sure that you have everything identified. You will need a standard phillips screwdriver to complete assembly.

2. Place the Table Top upside down on a carpeted surface. Position one of the legs in the inside corner as illustrated. Holding the leg tight against the corner, install three screws through the pre-drilled holes in the outside of apron and into the leg. The legs do not have pre-drilled pilot holes and may be oriented however you choose. Please make sure that the leg is firmly touching the two sides and the underside of the table when you start the screws. Screw in the wood screws until they are tight and the heads are slightly below the surface of the wood.

3. Now attach any two of the remaining three legs.

4. Turn the table over so that it is upright and place on a hard flat surface. Hold the fourth leg into position. The table should sit squarely on the floor and not rock. If it does rock, adjust the height of the leg until it sits flat on the floor. Now attach this last leg.

Care and Cleaning:

If this Chair is unfinished, it must be totally protected by an outdoor/exterior rated stain or house paint BEFORE being used outside. Exposure to any weather or even sun can cause rapid deterioration, cracking, warping, splitting and discoloration of unfinished wood.

If this Chair is painted, the finish is designed to provide long lasting protection when exposed to the harshness of weather. But no matter how durable, painted wooden furniture should not be left outdoors continually. It is best to store it inside when not in use. Even in mild conditions, painted wood furniture left outdoors will eventually fade and show the effects of exposure to weather. To clean your painted furniture, use a mild detergent such as a dishwashing liquid and a soft cloth. Never use any type of abrasive cleanser.

All of us at Little Colorado, Inc hope that you and your little ones enjoy this Adirondack End Table for many years. Please call us if you have any questions.

Manufactured in America by:

Little Colorado, Inc. 4450 Lipan Street Denver, Colorado 80211
Phone 303-964-3212 Fax 303-964-3213 info@littlecolorado.com

